



REF	PART	DESCRIPTION	REF	PART	DESCRIPTION	REF	PART	DESCRIPTION
1	13-1110	Stand Upright	10	13-1085	Crossarm Weldment	20	13-6025	End Reflector
2	13-1120	Stand Upright (Crimped)	11	13-1088	Male Knob 1/4-20 x 9/16"	21	13-6030	Guard
3	13-1103	Stand Crossbar	12	13-1095	Male Knob Rotator 3/8-16 x 1"	22	13-6035	Reflector
4	13-1101	Stand Leg (right)	13	13-1096	Female T KNob 1/4-20	23	10-6000	HO-2000-E 2000W 240V Element
5	13-1130	Stand Leg (left)	14	13-1097	Tab Washer w/ Bolt			
6	13-1130	2" Caster	15	13-6020	Crossarm Mounting Plate			
7	13-1140	Stand Frame Bolt 3/8-16 x 3/4"	16	13-6050	30 Amp Toggle Switch			
8	13-1140	Upright Fasteners 5/16-18 x 1-1/2"	17	13-6055	12 Ft. Cord			
9	13-1140	#6 Hex Head Slotted Screw	18	13-6060	Plug			

ASSEMBLING YOUR NEW SYSTEM

Unpack Your System: Check for visible damage and notify freight carrier if any exists. Carefully remove all packing, bubble pack, and cardboard boxes on the bottom of the pallet.

Secure Arm: The arm is pre-assembled and wired, ready to insert into the vertical posts of the main stand assembly. The brackets are designed to accept the arm and hold it in place while you use the same bolts that held the wooden shipping brackets in place to secure the arm.

Assemble Hardware: Unbolt the stand from the wooden shipping pallet and remove the system. Open the small cardboard box and remove the casters and hardware. Attach casters in the four holes provided using the lock

washers and nuts provided.

Install Elements: To prevent breakage, unit is shipped without the element installed. Open the long cardboard box and remove the quartz tubes. Remove the end reflectors and guard from each heater. There is a wire with ring terminal on each end of the heater (under the reflector). Connect the wires to the elements, taking care to get a tight connection. Insert the two elements into the two heaters on the arm assembly.

First Use: Refer to operating instructions before using the heater. For technical assistance, please call toll-free (800) 421-9455.

ELEMENT REPLACEMENT INSTRUCTIONS

Step 1: Check U/L label on heater for proper voltage.

Step 2: Remove end plates.

Step 3: Open element clips at each end of heater and carefully install quartz tube. Remove one nut from end of element. Slip on wire over element screw. Replace nut.

NOTE: Hold element ceramic firmly while tightening nut to prevent damage to element. Nut should be tightened snug, as a loose connection could cause element to fail.

Connect other side of element. Close element clips over tube.

Step 4: Replace end plates.

Step 5: Clean tube and reflector with alcohol or equivalent.

Step 6: Snap on provided grill.

BASIC OPERATING INSTRUCTIONS

Setup: Plug unit into appropriate power source.

To Adjust Systems Operational Height: Support the control panel handle and extension arms, then loosen the slide lock knob on the mast slide assembly. With one foot on stand base, lift or lower the entire assembly as needed. Normal operating position for most jobs is 1/2 way up the mast. Be sure to adequately re-tighten the slide lock knob after you have repositioned the slider to prevent system control assembly from moving.

Using the Extension Arm: To raise or lower the extension arm, simply depress the control handle located on the extension arms to the rubber stop and push up or down on the extension arms as required for positioning. Release the handle to lock in the desired position.

Heater Cassette Assembly: Can be swiveled 270° around extension arm. This makes a narrow foot print so the unit can work in tight locations. The heater head can also tilt

down 90° by loosen the locking knob and moving head down to the desired location.

Adjusting Heater Cassette: Each heater cassette can be individually adjusted to “clam shell” heat around corners or for door jambs. When heaters are rotated outward, the unit heats a larger area and requires a little more time to cure. When heaters are swiveled in, the cure time and area is reduced. Consider using at a lower temperature when heaters are swiveled in to prevent vehicle damage.

Heater Positioning: Position system so that the heater’s cassettes are from 18" to 36" away from the panel. **IMPORTANT NOTE: NEVER POSITION HEATERS CLOSER THAN 18" FROM TARGET AREA.** You should start out with the systems heater cassettes positioned out at 36" away from the surface until you get a feeling for the power of the system and how to use the controls. Then you can move in closer as required.

SYSTEM MAINTENANCE

With proper maintenance, your new Infratech system should give you years of reliable, productive service.

- 1. Every 4-6 months, unplug the system and remove end reflectors from heaters and re-check connection of lead wires to the elements.**
- 2. Oil from your hands damages elements. If you touch the elements, clean them with denatured alcohol and clean cotton swabs (make sure the elements are cool first).**
- 3. The reflectors on the heaters should be kept free of dust or over spray. Use a damp cloth or, if necessary, some fine steel wool or a Scotch-Brite® pad to clean residue.**
- 4. Blow off IR sensor and dust with a cotton swab weekly. Do not over spray sensor.**

CURING TIME

PAINT TYPE	DISTANCE FROM SURFACE	HEATED AREA (HO-6000-P)	HEATED AREA (HO-6000-P)	POWER INTENSITY SETTING (HO-6000-P)	DIGITAL TEMP. SETTING (HO-6000-P)	CURING TIME (HO-6000-P)	CURING TIME (HO-6000-P)
Water Based Primer	24"	4' x 4'	4' x 4'	80%	180°	6 min.	6 min.
Water Based Primer	36"	5' x 6'	4' x 6'	100%	140°	10 min.	10 min.
Solvent Based Primer	24"	4' x 4'	4' x 4'	80%	180°	15 min.	10 min.
Solvent Based Primer	36"	4' x 6'	4' x 6'	100%	140°	15 min.	15 min.

Lacquer	36"	4' x 6'	4' x 6'	100%	140°	15 min.	20 min.
High Solids Clear Topcoat	24"	4' x 4'	4' x 4'	80%	180°	18 min.	18 min.
High Solids Clear Topcoat	36"	4' x 6'	4' x 6'	100%	140°	20 min.	20 min.
Urethane Clear Coat	36"	4' x 6'	4' x 6'	100%	140°	20 min.	20 min.
Polyurethane Clear Coat	36"	4' x 6'	4' x 5'	100%	140°	20 min.	20 min.
Acrylic Enamel	36"	4' x 6'	4' x 6'	100%	140°	20 min.	20 min.

WORKING WITH INFRARED & PAINT

Every coating system, applicator and shop have many variables (type of material, thickness applied, type of reducer, air temperature, and ambient moisture content) that come into play when applying and curing coating systems. All these variables must be taken into consideration when setting curing time settings and power intensity settings. The following is our recommendation to establish the correct setting for your shop:

1. Mix paint for the current weather conditions in your area as recommended by manufacturer.
2. Start with an intensity setting of 75% power (default setting).
3. Set cure time according to product being cured (refer to curing time chart).
4. If the job is not cured, add more time at the same intensity to complete the job.
5. For the next job using the same materials, increase intensity 5% (or 10% max.) and use the same recommended time.
6. At the first sign of solvent pop, back the intensity down 5% and use that setting down 5%.

WARNINGS:

- NEVER block front of heater
- DO NOT operate within 25' of flammable materials
- DANGER: Do not use within 10' when spraying operations are in progress
- NEVER service heater without disconnecting from power
- Source of possible shock
- Use only with grounded power source
- Only use grounded extension cords that are rated for the amp load of these units

OPTIONAL ACCESSORIES

Optional Digital Controller: Available in six different models. Options include: Timer and Solid State Relay Zone Control. Units can be ordered surface mount for use with permanently installed fixtures or to mount on the crossarm of the HO-6000-P.

Optional Infrared Sensor: Available only on the one zone digital control. And can be focused on the target. The sensor enables the solid state control to hold surface temperatures + or - 3 degrees F.

SPECIFICATIONS

PART NUMBER	MODEL	DESCRIPTION	WATTS	BTU'S	VOLTS	AMPS
16-5000	HO-6000-P	Complete Portable Unit	6,000	18,846	240	25
16-5010	HO-6000-F	Fixture Only	6,000	18,846	240/spec.	25